



ROOMMATE

ROOMMATE is a 4 Zone Stereo Matrix Mixer, meaning that any of the 6 stereo input channels can be freely distributed to any of the 4 stereo zone outputs. Connect and control up to 3 microphones and 11 Stereo line sources, like CD players, Radio's, Satellite- and Cable- receivers in max 4 different rooms. As a bonus the additional Dual USB connections enable a 2-channel stereo audio feed from a MAC or PC.

Key Features:

- 5 line control channels plus separate mike section
- 11 stereo line and 3 mike inputs
- 3 band equalizer per channel
- 2 USB input channels for playback audio from a computer
- 2 pair stereo balanced XLR outputs for Master and Zone 1
- RCA outputs for Zone 3 and 4
- Recessed gain controls
- Recessed mono/stereo, master and zone switches
- Recessed and hide-able output volume controls
- Headphone output with cue/mix control

Specifications:

Inputs:

Line/Aux: 10Kohm input impedance
77mV rms sensitivity for 1.22V output
Mic: 600 ohm input impedance unbalanced
1mv rms sensitivity for 1.22V output

Outputs:

Line: 9V rms max
Headphone 0.5W into 47 ohm
S/N Ratio: >98 dB
Total Harmonic Distortion: <0.02% (1KHz)
Frequency response 20Hz~20KHz +- 0.5dB

Power Consumption:

AC 90-250V; 50Hz-60Hz; 21W

Dimensions:

Face Panel 483x177
Rear Panel 434x80mm
Depth 85mm including rubber feet

Weight: 4.0 KG